

# Big Boat Car Couplers

Often found on curved track, couplers join two cars to form high-load assemblies.

Use high-load 580 and 752 couplers for single-point attachments. Use 1799 control block with 580 or 1770 couplers. Use single, double or triple Black Magic® AirBlocks® with the 752 coupler.



| Part No. | Description         | Length |     | Weight |      | Safe working load |      | Breaking strength |      | Fits           |
|----------|---------------------|--------|-----|--------|------|-------------------|------|-------------------|------|----------------|
|          |                     | in     | mm  | oz     | g    | lb                | kg   | lb                | kg   |                |
| 580      | Coupler             | 7¼     | 184 | 21     | 595  | 6000              | 2722 | 12000             | 5443 | 3163           |
| 584      | Mainsheet carrier   | 10     | 254 | 44     | 1247 | 6000              | 2722 | 12000             | 5443 | 3163           |
| 752      | Coupler             | 10¾    | 273 | 28     | 794  | 9000              | 4082 | 18000             | 8165 | 3165           |
| 1770     | Flat plate coupler* | 4¾     | 111 | 3      | 84   | 3600              | 1630 | 8400              | 3810 | 3160/3163/3164 |

\*Custom flat plate coupler & modified 3165 & 3166 car assemblies available upon request


# Track Risers & Dodger Blocks

**Track Risers**


Use 1849 risers for mid-boom travelers that must clear companionway hatches. Risers fit most cabintops and articulate for use with either straight or curved track. Sold in pairs.

**Dodger Blocks**

These blocks route control lines to the deck from bridge-mounted travelers and pass under the dodger to cam cleats mounted within reach of the crew.



|          | in                              | mm  |          | in                             | mm  |
|----------|---------------------------------|-----|----------|--------------------------------|-----|
| <b>A</b> | 6 <sup>7</sup> / <sub>8</sub>   | 175 | <b>D</b> | 4 <sup>5</sup> / <sub>16</sub> | 110 |
| <b>B</b> | 9 <sup>9</sup> / <sub>16</sub>  | 243 | <b>E</b> | 1 <sup>3</sup> / <sub>4</sub>  | 45  |
| <b>C</b> | 6 <sup>11</sup> / <sub>16</sub> | 170 | <b>F</b> | 3                              | 76  |



| Part No. | Description                            | Fits                         | Weight |      |
|----------|--|------------------------------|--------|------|
|          |  |                              | oz     | g    |
| 1849     | Track riser (pair)                     | 1618/3156                    | 131.2  | 3720 |
| 1985     | 6:1 Dodger block conversion kit (pair) | 3185 Traveler control blocks | 8      | 227  |